

**VALVE NUT
REPLACEMENT
SYSTEM**

Save the streets.

Save time and money by replacing rounded or worn out operating valve nuts with new long-lasting stainless steel replacement nuts and avoid complete valve removal. Our complete Valve Nut Rx kit provides everything needed for successful nut replacement. Removing the worn nut is as easy as lowering the 7ft Nut Extractor; set, lock and lift. To measure correct new valve nut set old nut onto provided template to select proper sizing.

- Replace a rounded or inoperable OP nut.
- Replace a missing OP nut.
- Remove any corroded nut or bolt holding down an old OP nut.
- Replace the old retaining Nut or Bolt with a new SS Nut or Bolt.
- Drill and tap any valve stem, if needed to secure the new OP Nut



Intermountain Sales Inc.

3792 S. Lipan St. Englewood, CO 80110

Phone: (303) 762-1070 Fax: (303) 762-0996

May 18, 2018